


# BOCA WALK-IN TUBS

## AIR, WHIRLPOOL, CHROMATHERAPY AND OZONATOR SYSTEM

### 1 AIR PUSH KEYPAD Functions



### 1. AIR PUSH KEYPAD FUNCTIONS

### ADVANCED PROGRAMMING

#### A: TWO SPEED BLOWER

- 1<sup>st</sup> Press: Blower starts at high speed.
- 2<sup>nd</sup> Press: Blower changes to medium speed.
- 3<sup>rd</sup> Press: Blower stops.

#### B: ON/OFF PUMP

- 1<sup>st</sup> Press: The pump starts.
- 2<sup>nd</sup> Press: The pump stops.

#### C: CHROMATHERAPY

- 1<sup>st</sup> Press: Turn on the light in white.
- 2<sup>nd</sup> Press: Rainbow cycle – Low speed.
- 3<sup>rd</sup> Press: Rainbow cycle – High speed.
- 4<sup>th</sup> Press: Turquoise.
- 5<sup>th</sup> Press: Blue.
- 6<sup>th</sup> Press: Magenta.
- 7<sup>th</sup> Press: Red.
- 8<sup>th</sup> Press: Orange.
- 9<sup>th</sup> Press: Yellow.
- 10<sup>th</sup> Press: Green.
- 11<sup>th</sup> Press: Turn off the light.

Press and hold 2 sec. at anytime to turn off the chromatherapy.

#### INTEGRATED 20 MINUTE AUTOMATIC TIMER

Integrated 20 minute automatic timer on the complete system, except the ComfortWarm™ system. Count down starts with the first system turned on.

#### INTEGRATED 30 MINUTE AUTOMATIC TIMER

Integrated 30 minute automatic timer on the ComfortWarm™ system.s.

#### OZONATOR CLEANING CYCLE

A 15 minutes cleaning cycle begins one (1) hour after no more water is detected by the water detectors.

#### DRYING CYCLE

A 1 minute automatic drying cycle will start 20 minutes after the blower is turned off.