



# BOCA WALK-IN TUBS

AIR, WHIRLPOOL, CHROMATHERAPY, OZONATOR AND ComfortWarm™ SYSTEM

## 1 RGB BACKLIT KEYPAD Functions



## 2 AIR PUSH KEYPAD Functions



### 1. RGB BACKLIT KEYPAD FUNCTIONS

#### LED

### 2. AIR PUSH KEYPAD FUNCTIONS

#### A: ComfortWarm™ SYSTEM

- 1<sup>st</sup> Press: The ComfortWarm™ starts at high heat.
- 2<sup>nd</sup> Press: The ComfortWarm™ changes to medium heat.
- 3<sup>rd</sup> Press: The ComfortWarm™ changes to low heat.
- 4<sup>th</sup> Press: The ComfortWarm™ stops.

RED  
ORANGE  
YELLOW  
OFF

#### A: TWO SPEED BLOWER

- 1<sup>st</sup> Press: Blower starts at high speed.
- 2<sup>nd</sup> Press: Blower changes to medium speed.
- 3<sup>rd</sup> Press: Blower stops.

#### B: ON/OFF PUMP

- 1<sup>st</sup> Press: The pump starts.
- 2<sup>nd</sup> Press: The pump stops.

#### C: CHROMATHERAPY

- 1<sup>st</sup> Press: Turn on the light in white.
  - 2<sup>nd</sup> Press: Rainbow cycle – Low speed.
  - 3<sup>rd</sup> Press: Rainbow cycle – High speed.
  - 4<sup>th</sup> Press: Turquoise.
  - 5<sup>th</sup> Press: Blue.
  - 6<sup>th</sup> Press: Magenta.
  - 7<sup>th</sup> Press: Red.
  - 8<sup>th</sup> Press: Orange.
  - 9<sup>th</sup> Press: Yellow.
  - 10<sup>th</sup> Press: Green.
  - 11<sup>th</sup> Press: Turn off the light.
- Press and hold 2 sec. at anytime to turn off the chromatherapy.

### ADVANCED PROGRAMMING

#### INTEGRATED 20 MINUTE AUTOMATIC TIMER

Integrated 20 minute automatic timer on the complete system, except the ComfortWarm™ system. Count down starts with the first system turned on.

#### DRYING CYCLE

A 1 minute automatic drying cycle will start 20 minutes after the blower is turned off.

#### INTEGRATED 30 MINUTE AUTOMATIC TIMER

Integrated 30 minute automatic timer on the ComfortWarm™ system.

#### OZONATOR CLEANING CYCLE

A 15 minutes cleaning cycle begins one (1) hour after no more water is detected by the water detectors.